



# Sony NEX-5T Battery Replacement

In this guide you will learn how to remove the battery.

Written By: William Kleinman



## INTRODUCTION

The battery is the power source of the camera. You can recharge it through the camera or remove it and charge it separately.

## Step 1 — Battery



- Open the battery compartment by sliding the lock to the right.

## Step 2



- Push in the blue lever.
- i** The battery is on a spring so make sure you have control over it, or it might fly out.

## Step 3



- Pull the battery out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 06:05:57 PM.